

Type 8692/8792

Profinet

Supplement to Operating Instructions

Contents

1 Overview.....3

2 Objects.....4

2.1 Cyclic data.....4

2.2 Acyclic data.....5

2.2.1 Device Data (Index 0x00__).....5

2.2.2 Position Controller Parameter (Index 0x02__).....6

1 Overview

Used datatypes:

UINT8	8 bit: unsigned integer
UINT16	16 bit: unsigned integer
UINT32	32 bit: unsigned integer
REAL32	32 bit: float value IEEE 754
String	C-string

2 Objects

2.1 Cyclic data

Cyclic data are available on several slots / subslots.

Slot	Subslot	Index	name	description	access type	SIM-Card
0x01	0x01	0x0001	NamurStatus	Represents the device status ¹⁾ UINT8	RO	
0x02	0x01	0x0001	CMD	Position set point REAL32 in %	RW	
0x02	0x02	0x0001	POS	Current valve position REAL32 in %	RO	

1)

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Gateway: 0 - run 1 - stop 0 if no gateway is supported by device.	F(x): 0 - run 1 - stop 0 if no F(x) functionality is supported by device.	Namur mode: 0 - auto 1 - manual 2 - flashing		Namur state: 0 - normal 1 - diagnose active 2 - maintenance required 3 - out of specification 4 - warning 5 - error			

2.2 Acyclic data

2.2.1 Device Data (Index 0x00__)

2.2.1.1 Object Route Function

Slot	Subslot	Index	name	description	access type	SIM-Card
0x00	0x01	0x0001	Index / Subindex / NodeID		RW	
0x00	0x01	0x0002	Data length (write access)		RW	
0x00	0x01	0x0003	Value UINT32		RW	
0x00	0x01	0x0004	Value String		RW	
0x00	0x01	0x0005	result		RO	
0x00	0x01	0x0006	call/cancel		RW	
0x00	0x01	0x0007	Control Mode		RW	

2.2.1.2 Buerkert Device Description Object

Slot	Subslot	Index	name	description	access type	SIM-Card
0x00	0x01	0x0008	Device Name	Unique device name Visible string	RO	
0x00	0x01	0x0009	Ident Number	Device ID No. UINT32	RO	
0x00	0x01	0x000A	Manufacture Date	Visible string	RO	
0x00	0x01	0x000B	Software Ident Number	ID No. of firmware UINT32	RO	
0x00	0x01	0x000C	Software Version	Version No. of firmware UINT32	RO	
0x00	0x01	0x000D	Hardware Version	Version No. of hardware UINT32	RO	
0x00	0x01	0x000E	Serial Number	Serial No. device UINT32	RO	
0x00	0x01	0x000F	Product Code	Manufacturers product code (type number) UINT32	RO	

2.2.2 Position Controller Parameter (Index 0x02__)

Slot	Subslot	Index	name	description	access type	SIM-Card
0x00	0x01	0x0201	DBDx	Deadband of the position controller in % REAL32	RW	X
0x00	0x01	0x0202	KPopen	Proportional gain for opening the valve SINT16	RW	X
0x00	0x01	0x0203	KPclose	Proportional gain for closing the valve SINT16	RW	X
0x00	0x01	0x0204	mCHARACT	Charact curve selected 0: No charact curve 1:Charact Curve 1:25 2:Charact Curve 1:33 3:Charact Curve 1:50 4:Charact Curve 25:1 5:Charact Curve 33:1 6:Charact Curve 50:1 7:FREE (See0x2C11 for defining the values) See User Manual for description of the function. SINT16	RW	X
0x00	0x01	0x0205	CUTOFFmin	Lower CUTOFF level in % SINT16	RW	X
0x00	0x01	0x0206	CUTOFFmax	Upper CUTOFF level in % SINT16	RW	X
0x00	0x01	0x0207	POSmin	Lower position for X.LIMIT in % SINT16	RW	X
0x00	0x01	0x0208	POSmax	Upper position for X.LIMIT in % SINT16	RW	X

0x00	0x01	0x0209	XTIMEopen	Limited opening time of the valve in s (X.TIME) REAL32	RW	X
0x00	0x01	0x020A	XTIMEclose	Limited closing time of the valve in s (X.TIME) REAL32	RW	X
0x00	0x01	0x020B	mDIRact	0: Rise (lower position > 0%) 1: Fall (upper position-> 100%) See User Manual for description of the function. SINT16	RW	X
0x00	0x01	0x020C	mSAFEpos	Position used as safepos in % SINT16	RW	X
0x00	0x01	0x020D	TUNEflags	0 if last tune was successful UINT8	RO	
0x00	0x01	0x020E	Menu_Items	Bitfield to Activate/Deactivate functions from ADD.FUNCTION menu Bit0 – Bit6: unused Bit7: CHARACT Bit8: CUTOFF Bit9: DIR.CMD Bit10: DIR.ACT Bit11: SPLTRNG Bit12: X.LIMIT Bit13: X.TIME Bit14: X.CONTROL Bit15: P.CONTROL (only 8693/8793) Bit16: SECURITY Bit17: SAFEPOS Bit18: SIG.ERROR Bit19: BINARY.IN Bit20: OUTPUT Bit21: CAL.USER Bit22: SET.FACTORY Bit23: SERVICE.BUES Bit24: EXTRAS Bit25: POS.SENSOR (only type 879X) Bit26: SERVICE Bit27: SIMULATION Bit28: DIAGNOSE Bit29: F.CONTROL (only with FMR option)	RW	X
0x00	0x01	0x020F	startTune	Start Tune via fieldbus 2: X.Tune startTune is set back from device 0:TUNE successfully started 255:TUNE could not be started Tune has finished when zOPmode changed back to Auto or Manual mode. Get result of last tune by reading object TUNEflags *since Release B.02.01	RW	
0x00	0x01	0x0210	z_OPmode	Get the current operating mode 0: Auto 1: Hand 2: X.Tune *since Release B.02.01	RO	